

INTEGRA 1.18 2018-06-20

Added:

- arming zones (reaction type 80 and 82) gives event when failed
- new reaction type "97.Reporting trouble of fire control panel" ([CID:200](#))
- INTEGRUM option for ETHM-1/INT-GSM
- arming failed event after sms control
- status of "station 1/2 A/B test" at event log
- added handling of INT-GSM
- connection supervision of INT-GSM when connected to ETHM-1 PLUS(RS485)

Changed:

- delete expansion module troubles after identification, even if no expansion module on bus
- SIA codes
 - code 126 - added code "BS" (without "RESTORE")
 - code 143 - added code "TA" / "TR"
 - code 300 - added code "ET" / "ER"
 - code 306 - code "YG" position replace (without RESTORE to RESTORE)
 - code 575 - added code "UB" / "UU"
 - code 625 - code "YU" added to RESTORE
- backlight off on AC loss
- arming/alarm status of LED on keypad
- lack of "Wrong code" message during macro command
- door opening using LCD(code+card) and INT-RS the same like in INT-S (lock mode "closed when armed")
 - adding ARU-100 to INTEGRA 128-WRL unavailable
 - question "1=Yes 2=No" after press * in partition timer edition
 - event 339 "Module restart" changed to 970 "Connection started" when DLAODX/GUARDX connecting
 - at "Station 1 and Station 2" reporting mode, back from Station 2 to 1 after 3 second delay between events
 - timeouts for reporting via ETHM-1(75s to 180s)

Improved:

- adding ASP-100 up to 8th and INT-KWRL up to 4th to ACU from keypad
 - multiplying "Service mode start" event at event log
 - timers edit
-

DLOADX 1.18.000 26-06-2018

- Customize the software to handle new FW for INTEGRA 1.18